


## 6' or 8' Bench Frame with Arm Rest – Portable

Tools required: drill (not included). One to two person assembly recommended.

### PARTS




### ASSEMBLY

#### STEP 1

Using drill & Torx bit to fasten cap screws:


1. Lay side-by-side four boards in this order, holes facing up – B, A, A, A.
2. Attach one bench frame using eight 2.25" cap screws. Rotate B board 180° if necessary so that predrilled holes line up.
3. Repeat #2 using bench frames and 2.25" cap screws.
4. Set upright.



#### STEP 2

Using drill & Torx bit to fasten cap screws:

1. Attach one A board to bench frame using six 2.25" cap screws.
2. Attach B boards using six 2.25" cap screws. Rotate 180° if necessary so that pre-drilled holes line up.
3. Set upright.




# ASSEMBLY

## STEP 3

Using drill & Torx bit to fasten cap screws:

1. Attach one arm to bench frame using four 2.25" cap screws.  
Hole size is 3/16".
2. Attach other arm to bench frame using four 2.25" cap screws.  
Hole size is 3/16".



## Fully Assembled

